

INSTRUCTIVO DE ARMADO

SKU 951

Ax1	Gx5
Bx1	Hx1
Cx1	Ix2
Dx2	Jx4
Ex1	Kx6
Fx1	Lx3
Mx1	Nx1

1

2

3

4

5

6

7

8

9