

STEP 5:



- ⑦ Control Box
- 8 Handset
- M4×12 Screws

STEP 6:



* 2

* 5

- 9 Wires
- (H) Cable Clips
 - cable Clips

Assembly Instruction



- -Office Desk
- -Electric lifting table

Ready To Use

Before Plugging the table into the outlet, make sure that

* 1 * 2

- The lift columns are level and set at the lowest position.
- All the screws are tightened, to avoid the desk making noise and wobbling.

Activate the desk by following the next steps.

- -Please press button down and hold for 10-15 seconds until it stutters and beeps.
- -Release the button, then your desk is ready to use.

Operation Guide

- 1. Memory desired height
- -Press button "M", display show "S-" with flash.
- -Press number and set desired position.


2. Advanced Safety feature- lock and unlock the table.

- -Press button up and down at same time for 5 seconds, display "LOC"
- -All single button will be inactive and table will be unable to move.
- -Pressing button up and down together willunlock the keypad and release the LOC

3. Reset the table

When display show Error code or RST, Please reset the table.


- -Unplug the power cord from the control box.
- -Unplug the cable that links the keypad to the control box.
- -Wait 30 minutes and plug all the cables in again.
- -Do the reset: please press button down and hold for 10-15 seconds until it stutters and beeps.



Press by holding 10-15 seconds


If the keypad displays HOT, please unplug and replug and let it cool off for a couple of minutes before proceeding again.

Installation tips




Please don't tighten the screws completely and go back later for a final tightening of all the screws after pieces are aligned with each other.

Lay a mat or old blanket out to assemble onto so the floor and the furniture doesn't get scratched or damaged during building.





STEP 1:



* 2

* 2

* 8


* 2

* 4

*10

- Lift Column
- Base
- Leveling Studs
- ® M6×16 Screws

STEP 2:



* 2

* 8


- - * 2 * 4

STEP 3:

Crossbar


A M6×12 Screws

Crossbar Center Rails



- Side Bracket
 - M6×8 Screws
- Washers

STEP 4:



- M5×18 Screws
- M8×10 Screws